

GERMAN RAILWAY SCHWERER PLATTFORMWAGEN TYPE SSYS

modelcollect



ITEM NO:UA72086

●READ BEFORE ASSEMBLY

1. When you use glue or paint, do not near flame, and use in a well-ventilated room.
2. Take extra care in handling photo etch parts in order to avoid injury.
3. When you take parts off the runner frame, use modeling scissors and trim excess plastic with a cutter or a file.
4. Glue and paint are not included.
5. This product is only suitable for experienced more than 14 years old.



SUPERGLUE
强力胶



WEIGHT
配重



MAKE HOLE
钻孔



CUT/REMOVE
切除




BEND
弯曲



FILE/SAND
锉平



OPTION
选择



NO CEMENT
不涂胶水




DECAL
贴纸

DECAL APPLICATION

1. Cut off decal from sheet.
2. Dip the decal in tepid water 40° C for about 10 sec. and place on a clean cloth.
3. Hold the backing sheet edge and slide decal onto the model.
4. Move decal into position by wetting decal with finger.
5. Press decal gently down with a soft cloth until excess water and air bubbles are gone.


水贴纸的使用:

1. 从水贴纸上剪下印花。
2. 将印花放入温水中浸10秒，然后放在干净布上。
3. 拿着印花纸板将印花移到模型上。
4. 手指蘸水将印花移到适当的位置。
5. 用软布轻压印花直至不干，汽泡消失。



C x 4

B x 4




A x 4


Decal X 2




1




2




4




5




6




7



8



9




WWII German Railway

Schwerer Plattformwagen Type Ssys

for Deutsche Reichsbahn | 1/72 Scale

modelcollect



A.MIG-008
RAL 7021 DUNKELGRAU

For a better result when painting your model it is highly advisable to follow weathering techniques.